



3. Radiometric Calibration & HDR




The Physical Meaning of Pixel Values








42




Preliminary Terms



Radiance






Light emitting (or reflecting) from a surface.

Only a light source would emit light, most things reflect light.

Radiance is measure in watts per steradian per square meter

• Irradiance



Amount of light falling onto a surface.

Irradiance is measured as watts per square meter

Note, that radiance and irradiance are fundamentally different.

Scene Radiance



Amount of radiance in a 3D scene varies greatly




Each point is a different radiance reading


From Radiance to Pixel Values



Many steps from the scene to the final pixel value 'z'.




- 1. Scene generates radiance L
- 2. This can be attenuated through a lens, then hits the imaging devices sensor (now we call it irradiance, E)
- 3. E is exposed for Δt seconds. The product (E Δt) is the exposure
- 4. Film has a response curve to $E \bullet \Delta t$. This response is often not linear; The development process may also not be linear.
- 5. If we are using a digital camera, the CCD response is linear!
- 6. However, this response is quantized
- 7. And typically (almost always) "6" is remapped through a noncurve to behave like film, so even though the CCD is linear, we get back a non-linear response!



many steps in the re-mapping



- This is called the Image Signal Processor (ISP) in a camera
- A typical pipeline:




Theory and Applications of Smart Cameras, Kyung C-M, Springer 2016


sample: auto white balance

- The light source affects the color of the scene objects
- Human eyes can correct this color bias
- Auto-white-balance
 - Identify the illuminant color
 - Neutralize the color of the illuminant (often by scaling the R, G, B values respectively)















$$\begin{bmatrix} R' \\ G' \\ B' \end{bmatrix} = \begin{bmatrix} S_r \\ S_g \\ S_b \end{bmatrix} \begin{bmatrix} R \\ G \\ B \end{bmatrix}$$

(source: www.cambridgeincolour.com)

sample: vignetting

- Irradiance is proportional to
 - projected area of aperture as seen from pixel
 - projected area of pixel as seen from aperture
 - distance² from aperture to pixel
- Combining all these
 - each ~ a factor of cos θ
 - light drops as $\cos^4\theta$
- Calibrating
 - take a photo of a uniformly white object
 - the picture shows the attenuation, divide the pixel values by it



sample: noise reduction



- Most image details occur repeatedly
- Image self-similarity can be used to eliminate noise

- Each color indicates a group of squares which are almost indistinguishable
- Average the squares of the same color to denoise




Image and movie denoising by nonlocal means, Buades, Coll, Morel, IJCV 2006

From Radiance to Pixel Values



- Film response curve
 - Toe region: the chemical process is just starting
 - Middle: mostly linear, if some amount of light turned half of the crystals to silver, the same amount more turns half of the rest
 - Shoulder region: close to saturation




The 'geography' of the characteristic curve of a negative material

From Radiance to Pixel Values



- Digital camera response curve
 - Modern cameras might have scene dependent processing, or even spatially variant processing
 - Making the curve impossible to calibrate or inverse! (let's ignore it for today)



Questions?



Radiometric Calibration



- Cameras have non-linear responses in terms of exposure $(E \bullet \Delta t)$
- Radiometric calibration amounts to recover the response function as:

$$Z_{ij} = f(E_i \bullet \Delta t_j)$$

Here Z_{ij} is the final pixel value (from 0-255) at pixel i, E_i is the irradiance at i, Δt_j is the shutter speed


Thus: $E_i \cdot \Delta t_i$ is the exposure of light on pixel i

Why Radiometric Calibration?



- Application 1: radiometric image analysis
 - Reflectance capture (Chapter 4)
 - Photometric stereo (Chapter 4)
 - Shape-from-shading
- Application 2: HDR (High Dynamic Range) imaging (today)
 - To capture both dark and bright areas in an image







Conventional Tricks for HDR



Use fill-in flash lights to reduce contrast

Vue à travers une fenêtre

Les scènes comportant une vue extérieure prise dans un intérieur sont très difficiles à réaliser. Dans ce cas, la mesure pour la zone lumineuse de la fenêtre 1 (sur le schéma ci-dessous) donne un résultat acceptable,


dessous à droite) pas plus satisfaisante pour l'extérieur que pour l'intérieur. La solution adoptée consiste à éclairer l'intérieur avec un flash diffusé 4, pour faire venir des détails à l'intérieur tout en conservant une vue détaillée de l'extérieur. La distance du flash a été calculée comme indiqué ci-dessous.




Exposure for outside



Exposure for inside



Average exposure



Using fill-in flash

Conventional Tricks for HDR



Use neutral density filters to reduce contrast



No filter: sky is too bright



Vertical neutral density gradient

Steps of HDR Imaging (& Radiometric Calibration)




• Step 1: Capture Images with different exposure (e.g. by varying the shutter speeds)












Assume scene is static, camera is static, and lighting is static, so all images are in register

Steps of HDR Imaging (& Radiometric Calibration)



• Step 2: Recover the camera response curve and the HDR image

The response curve transfers a pixel value to an exposure value (essentially # of photons)



For each pixel in each image convert the pixel value (an integer within [0,255]) to scene exposure value












Average exposure values from different images to denoise

Steps of HDR Imaging (& Radiometric Calibration)



- Step 3: remap the exposure value back to integers within [0,255]
 - → Because displays and printers only support that format
 - → To reduce the dynamic range, but preserve all the details








How to Change Exposure

- Ways to change exposure
 - Shutter speed
 - Aperture
 - Natural density filters
- Exposure times usually obey a power series
 - each "stop" is a factor of 2
- Camera settings say:

¼, 1/8, 1/15, 1/30, 1/60, 1/125, 1/250, 1/500, 1/1000 sec In reality is:

¼, 1/8, 1/16, 1/32, 1/64, 1/128, 1/256, 1/512, 1/1024 sec








Questions?



Camera Response Calibration



• The non-linear mapping between exposure and pixel values.




Exposure = (Irradiance *
$$\Delta t$$
) (CCD photon count)

The Algorithm



Input Images



Pixel Value Z = f (Exposure)


Exposure: irradiance $\cdot \Delta t = \#$ of photons (per pixel)

 $\log Exposure = \log Irradiance + \log \Delta t$

$$g(Z) = \log f^{-1}(Z) = \log Irradiance + \log \Delta t$$

The Algorithm

- Plot the observations from a single pixel
 - $g(Z) = \log Exposure = \log Irradiance + \log \Delta t$
- Obtain a log-curve in the "Pixel Value Exposure" space
- A different pixel generate a different curve




The horizontal offset of each curve is the unknown irradiance E_i at each pixel i



The Algorithm



 We can estimate the irradiance of all pixels to align these pieces to a smooth curve



The Math



For each pixel site i in each image j, want

$$ln E_i + ln \Delta t_j - g(Z_{ij}) = 0$$

- # of unknowns: N + 256 (N is the # of pixels)
 - g(Z) is determined by g(0), g(1), ... g(255)
- # of equations: NK (K is the # of images)
- Minimize the following

$$\sum_{i=1}^{N} \sum_{j=1}^{P} \left[\ln E_i + \ln \Delta t_j - g(Z_{ij}) \right]^2 + \lambda \sum_{z=Z_{min}}^{Z_{max}} \left[g(z) - \frac{g(z+1) + g(z-1)}{2} \right]^2$$
fitting term
smoothness term

• The solution can be only up to a scale, add a constraint

$$g(128) = 0$$

$$g''(z) = 0$$

How to Optimize?



$$\sum_{i=1}^{N} \sum_{j=1}^{P} \left[\ln E_i + \ln \Delta t_j - g(Z_{ij}) \right]^2 + \lambda \sum_{z=Z_{min}}^{Z_{max}} \left[g(z) - \frac{g(z+1) + g(z-1)}{2} \right]^2$$

1. Set partial derivatives to zero

derivatives to zero
$$\min \sum_{i=1}^{N} (\mathbf{a_i x} - \mathbf{b_i})^2 \rightarrow \text{linear equations of} \begin{vmatrix} \mathbf{a_1} \\ \mathbf{a_2} \\ \vdots \end{vmatrix} \mathbf{x} = \begin{vmatrix} \mathbf{b_1} \\ \mathbf{b_2} \\ \vdots \end{vmatrix}$$

2. Solve the linear equation (over-determined, i.e. more equations than unknowns)

$$\mathbf{A}\mathbf{x} = \mathbf{b} \longrightarrow \mathbf{A}^T \mathbf{A}\mathbf{x} = \mathbf{A}^T \mathbf{b}$$

$$\underset{m > n}{m \times n}$$

Matlab code



```
% gsolve.m - Solve for imaging system response function
% Given a set of pixel values observed for several pixels in several
% images with different exposure times, this function returns the
% imaging system's response function g as well as the log film irradiance
% values for the observed pixels.
% Assumes:
 Zmin = 0
 Zmax = 255
 Arguments:
  Z(i, 1) is the pixel values of pixel location number i in image 1
         is the log delta t, or log shutter speed, for image j
         is lamdba, the constant that determines the amount of smoothness
  w(z) is the weighting function value for pixel value z
 Returns:
  g(z) is the log exposure corresponding to pixel value z
  lE(i) is the log film irradiance at pixel location i
```

Matlab code



```
function [q,lE]=qsolve(Z,B,l,w)
n = 256;
A = zeros(size(Z,1)*size(Z,2)+n+1,n+size(Z,1));
b = zeros(size(A, 1), 1);
k = 1;
       %% Include the data-fitting equations
for i=1:size(Z,1)
  for j=1:size(Z,2)
    wij = w(Z(i,j)+1);
   A(k, Z(i, j) + 1) = wij; A(k, n+i) = -wij; b(k, 1) = wij * B(i, j);
   k=k+1;
  end
end
A(k, 129) = 1; %% Fix the curve by setting its middle value to 0
k=k+1;
for i=1:n-2 %% Include the smoothness equations
 A(k,i)=1*w(i+1); A(k,i+1)=-2*1*w(i+1); A(k,i+2)=1*w(i+1);
 k=k+1;
end
x = A \setminus b;
               %% Solve the system using SVD
q = x(1:n);
                                29
1E = x(n+1:size(x,1));
```


Results: Camera Response Function



Kodak DCS460 (1/30 to 30 sec)



Recovered response curve



log Exposure

30

Example: Input Images






Example: Recovered Radiance Map



W/sr/m2 121.741 28.869 6.846 1.623 0.384 0.091 0.021 0.005



Irradiance map, sometimes also called radiance map

••

Ignoring the vignetting effect, irradiance is proportional to the scene radiance

Questions?






Modeling the Space of Camera Response Functions


Michael D. Grossberg, Member, IEEE Computer Society, and Shree K. Nayar

PAMI 2004

Empirical Model of Response Functions







- Measure response functions of many real cameras
- PCA to obtain a linear parametric model of the response function
- Further enforce monotonicity




Radiometric Calibration from a Single Image

Stephen Lin[†] Jinwei Gu[‡] Shuntaro Yamazaki[§] Heung-Yeung Shum[†]

CVPR 2004

Edge Color Distributions






- Pixels on edge blend two colors
- They should lie on a line connecting the two colors
- Due to nonlinear camera response, these blended pixels form a curve
- So we can find the (inverse of) camera response curve by making these curves straight lines

Camera Linearization





- Automatically choose edges in an image
- Measure the nonlinearity at these edges
- Use the PCA response function model from Grossberg and Nayar
- Find the best parameter to minimize the nonlinearity

Questions?

